



POS.	DESCRIPTION	PART.NO.
1	FRONT PANEL	351 141
2	HANDLE 109MM	351 214
	SCREW M5x12	349 615
3	KNOB Ø22	347 348
	POTENTIOMETER	348 430
	NUT M7x0.75	347 249
4	LED GREEN Ø3mm	336 398
5	LED RED Ø3mm	336 399
6	SCREW M5x12	349 532
7	GRILLE	351 328
8	KNOB	341 382
	MAINS SWITCH	346 720
	SCREW M3x6	334 989
9	COVER	351 359
10	SCREW M3x6	334 989
11	STRAIN RELIEF	349 768
12	POWER CORD	353 914
13	SLIDE SWITCH	338 886
14	TAPPING SCREW 3.9x9.5	348 583
15	SWITCH	348 583
16	XLR CONNECTOR (MALE)	346 792
17	XLR CONNECTOR (FEMALE)	346 791
18	SWITCH	348 572
19	SCREW PT-KB 30x8	344 229
20	REAR PANEL (TOP)	351 142
21	REAR PANEL (BOTTOM)	351 143
22	SPEAKON CONNECTOR	341 343
23	HOLE, PLUG Ø18.5MM	341 343
24	RIVET	335 632

[illegible]