



When wire 1 & 2 are connected, the relay gets operated. But now I want to use SK 100 in place of SL 100, so how should the above circuit be designed.