



ASTABLE MULTIVIBRATOR

IF YOU WANT TO SPEED UP OR SLOW DOWN THE CIRCUITS FLASH RATE YOU CAN ALTER THE TIMING COMPONENTS-R1,R2,C1,C2