

TOSHIBA

FILE NO. 810-200555

SERVICE MANUAL




DVD VIDEO PLAYER



SD-4980SC

SD-4980SU



PARTS LIST

Location No.	TSB P/N	Reference No.	Description
AH700347	043-000168-000	REMOTE CONTROL HANDSET SE-R0168 (C.G), w/o WEEE MARK (PbF)	
AH700348	122-004220-120	AV CABLE 1.2M COAXIAL	
AH700349	122-005020-005	HDMI CABLE 1500mm	(For TC Version)
⚠ AH700351	811-498091-010	MANUAL - English	(For TC Version)
⚠ AH700352	811-498091-020	MANUAL - French	(For TC Version)
⚠ AH700353	811-498091-030	MANUAL - Spanish	(For TU Version)
⚠ AH700354	811-498091-040	MANUAL - English	(For TU Version)

SAFETY PRECAUTION

The parts identified by ⚠ mark are critical for safety. Replace only with part number specified. The mounting position of replacement is to be identical with originals. The substitute replacement parts which do not have the same safety characteristics as specified in the parts list may create shock, fire or other hazards.

IN-WARRANTY SERVICE

In-Warranty service for the SD4980 DVD Player is fulfilled via product exchange. Contact Toshiba Customer Solutions for instructions:
1-866-583-7353

TOSHIBA CORPORATION

1-1, SHIBAURA 1-CHOME, MINATO-KU, TOKYO 105-8001, JAPAN