


## LED Digital Panel COMBO Amp & Voltmeter


### The Installation & Wiring Diagram

#### Dimensions of Cutout




The meter can be installed in any panel w/ thickness of 0.5mm - 10.0mm .

#### Power & Signal Wiring



Please kindly note the following:

- 1) Shunt & Load must be used if the meter is used to read amps (current);
- 2) Shunt must be connected between the **NEGATIVE** terminal and the Load;
- 3) Load must be **activated** when measuring amps (current);
- 4) Please ignore the colours of the wires, and note that the amp meter must be connected in **SERIES** while the volt meter should be connected in **PARALLEL**;



Please consult your licensed electrician/electrical engineer for professional advice before installation.